

## Spark Indicator

This non-contact spark tester will test for the presence of power on spark plugs, coils and distributors. Simply place the grooved end over the spark plug wire with the engine running and the high intensity bulb will flash indicating spark. Pen type pocket clip for handy use. CE certificated and RoHS compliant.



### Additional Information

- Non-contact spark tester.
- Tests presence of power on spark plugs, coils and distributors.
- Simply place the grooved end over the spark plug wire with the engine running and the high intensity bulb will flash indicating spark.
- Pen type pocket clip for handy use.
- CE certified and RoHS compliant.

<http://gunson.co.uk/product/77077>

